

Congratulations! You are installing the newest technology 1946-48 Plymouth taillights from Shiny-Hiney.com. Here are some fun facts about your new taillights:

Four Wire Connection. A four (4) wire connection with a dedicated turn signal wire is included. The onboard micro-controller will determine whether to flash the turn signal or not based on the particular situation (ie. Brake on or off). Use of the fourth wire is optional depending on the customer's vehicle.

RapidFire™ Your taillights are equipped with our new RapidFire™ stop light system. Every time the brakes are used our lights will flash for three times in rapid succession followed by a constant on. This cycle is repeated every time the brakes are used. This valuable safety feature helps ensure the visibility to other drivers.

Pulse width modulated tail lamp. The reduced intensity taillight now is a rapid pulsing of the LEDs on and off (on for 10% and off for 90% of the time). This pulsing repeats 2000 times per second. Since the LEDs are only on for 10% of the time, their life is increased. The DOT defined minimum brightness ratio of 7:1 between tail and stop light is exceeded to 10:1.

Body seal and internal seal Unlike Plymouth, we include a molded rubber taillight to body seal. The internals are also sealed with a high quality gasket.

Stainless Steel All parts on your taillight are non-corrosive or stainless steel, including the hardware.

Lifetime Warranty

Proudly MADE IN USA

1946-48 Plymouth Installation Instructions

1. **Disconnect Battery.** **Do not skip this step.** Also, do not try to "test" the LED array by connecting the leads directly to your battery. Permanent damage will occur to the LED array if you fail to heed these steps.
2. Remove the old taillights from the car.
3. Install the provided taillight to body gasket between the taillight and the body.
4. Pass the supplied LED harness through the 3/8" hole and position the taillight on the body. Tighten the supplied 1/4" stainless steel lock-washers and flanged nuts.
5. Repeat for the other side of the vehicle.
6. **Wiring for cars with 2 taillight wires + ground.** Using the supplied connectors, connect the wire from the taillight circuit to the **black** wire on the supplied harness. See "Quick & Easy" instructions to use the supplied connectors. Repeat by connecting the wire from the brake light circuit on your car to the **red** wire on the supplied harness. The **green** wire is connected to a good body ground. If you do NOT desire the **RapidFire™** feature connect the wire from the brake light circuit on your car to the **yellow** wire on the supplied harness.
7. **Wiring for cars with 3 taillight wires + ground.** Using the supplied connectors, connect the wire from the taillight circuit to the **black** wire on the supplied harness. To use the connector, see the instructions below. Repeat by connecting the wire from the brake light circuit on your car to the **red** wire on the supplied harness. The **green** wire is connected to a good body ground. Connect the wire from the turn signal circuit on your car to the **yellow** wire on the supplied harness.

8. Repeat for the other side.
9. Reconnect the battery.
10. Test both STOP and taillight functions.
11. Enjoy!
12. **Turn signals:** If the tail and stop functions both work after installation but the turn signals do not, replace the turn signal flasher with a new one of the same number. Do not use a "heavy duty" flasher. An electronic flasher may be necessary if your car has LED front parking lights or no front parking lights at all.

Wiring review

- Green – Ground
- Red – Stop
- Black – Tail
- Yellow – Turn

QUICK & EASY!

1 Strip wire to 1/2"



2 Twist



3 Insert



4 Hand tighten



Email: sales@shiny-hiney.com

www.shiny-hiney.com